

## PARTS AND ACCESSORIES



## Why not trust your parts to the people who built your truck?

The peace of mind you get from genuine Vac-Con replacement parts and accessories comes from 25 years of experience building quality trucks. No one knows your truck like we do. Our parts are engineered to your original equipment specifications and we will stand behind every part we make.

## Who We Are

Vac-Con is a leading manufacturer of environmental products located on 16 acres in northeast Florida and has 100,000 square feet of manufacturing floor space. 250 employees work hard to bring you the best sewer cleaning, industrial vacuum and hydroexcavator products in the industry. We have been here since 1986 and will continue to bring you unsurpassed products and services.




## When Ordering Parts

Replacement parts should be ordered through your local authorized Vac-Con dealer. Genuine parts and service are available at their facility to provide the fastest possible delivery. A complete inventory of standard parts are on hand at our factory headquarters in Green Cove Springs, Florida, USA. This includes replacement parts, pumps, and power units. Normally, Vac-Con does not stock spare parts for nonstandard options and accessories you may have originally ordered. An order placed for standard parts at our headquarters office will normally be shipped within 24 hours after receipt of order. Orders should be placed prior to 5:00 PM E.S.T. Monday through Friday.

## Vac-Con Serial Number Designation

When ordering parts, always specify your unit serial number and Vac-Con Model Number. Your 7 or 8 digit serial number is located on a metal plate mounted to the Vac-Con module.



## Contacting Us

Vac-Con, Inc  
969 Hall Park Drive  
Green Cove Springs, FL 32043  
Ph: 904.284.4200  
Fx: 904.529.7874  
[www.vac-con.com](http://www.vac-con.com)  
email: [partsdepartment@vac-con.com](mailto:partsdepartment@vac-con.com)

## Limited Replacement Part Warranty

Seller warrants for 30 days from the date of sale that the equipment sold, as described hereon, shall be free from defects in material and workmanship. Seller's liability under this warranty is limited to repair or replacement of any part or parts of said equipment which shall be returned to seller, shipping charges prepaid and which seller's examination discloses to its sole satisfaction to be defective. This is seller's only warranty. By accepting the equipment under this warranty, buyer acknowledges that said equipment is being sold under no other written or oral warranties, neither expressed or implied.

## Freight Policy

Unless otherwise requested by the buyer, material will be shipped via carriers of our choice with shipping, handling and packaging charges prepaid and added to the invoice. Note: We only insure if specifically requested by the buyer, with insurance charges prepaid and added to the invoice.

## Damaged Shipment

Merchandise shipped is carefully packed in compliance with carrier requirements. Title and risk of loss pass to the customer upon tender of shipment to the carrier. If product is damaged in transit, consignee must file claim with the carrier.

## Returned Material Policy

We will normally accept returned material under the following conditions:

- A copy of the order number is furnished.
- The material is returned within 30 days from date of invoice.
- The material is in new resalable condition (unused, unpainted, etc.).
- The material is normal stock for us (not special order).
- Please call for a Return Authorization Number (RMA) prior to returning any material.
- Returned material must be accompanied with the RMA Number.

# Table of Contents



Bearings 6



Belts 7



Boom 8



Debris Tank 10



Electrical 13



Hose And Fittings 21



Hose Reel 27



Hydraulics 31



Miscellaneous 36



Safety 37



Sewer Cleaning 39



Tool Box Parts 42



Tools 44



Vacuum 45



Valves 52



Water System 55

Index 60



▲ Pillow Block Bearing  
 (for use on Sewer Cleaning Hose Reels)  
 644-0003



▲ Pillow Block Bearing  
 (for Vacuum Compressors)  
 644-0008



▲ Flange Bearing  
 (for Vacuum Compressors)  
 644-0009



▲ Bearing Support Post  
 (for Vacuum Compressors)  
 810-1694



▲ Flange Bearing  
 (for Vacuum Compressors)  
 644-0010



▲ Flange Bearing  
 (for Auxiliary Engines that Drive Water Pumps)  
 644-0188




## ◀ Water System and Belt Drive Vacuum Belts


Part No.	Description
640-0001	5VX1180 3 Rib
640-0002	5VX950 3 Rib
640-0003	5VX1000 3 Rib
640-0004	5VX1250 3 Rib
640-0005	5VX1060 3 Rib
640-0006	5VX1060 4 Rib
640-0007	5VX750 3 Rib
640-0008	5VX1250 4 Rib
640-0009	5VX1120 3 Rib
640-0010	5VX1120 4 Rib
640-0011	5VX750 4 Rib
640-0012	5VX1400 3 Rib
640-0013	5VX1180 4 Rib
640-0027	5VX1320 3 Rib
640-0028	5VX1000 4 Rib
640-0029	5VX1320 4 Rib
640-0030	5VX800 3 Rib
640-0040	5VX950 6 Rib



▲ Hydrostatic Pump Drive Belt  
640-0020



▲ Boom Gear Box  
646-0035



▲ Boom Rotation Chain  
642-0015



▲ Boom Tie Down Latch  
690-0126



▲ Connecting Link  
(for Chain 642-0015)  
642-0010



▲ Seal Kit  
(for Telescopic Boom Hydraulic Cylinder 711-4095)  
711-7442





▲ Boom Elbow Weldment  
800-0128  
800-9125 (wear back)



▲ Boom Elbow Weldment  
800-4587  
800-6173



▲ Boom Elbow Weldment  
800-7566 (for 800-4587)  
800-7964 (for 800-6173)



▲ Boom Elbow Weldment  
800-8934 (for 800-6173)  
800-8443 (for 800-4587)  
800-8684 (for 800-6206)



▲ Reducer Weldment  
800-5926



▲ Boom Hose Reducer  
800-3007



▲ Outlet Seal  
690-0847



▲ Inlet Seal  
690-0848



▲ Outlet Seal  
690-0847

## DEBRIS TANK INLET/OUTLET SEALS



▲ "V" Screen Weldment  
800-1459



▲ Vacuum Breaker Door Seal  
690-0440



▲ Vacuum Breaker Lid Seal  
690-0444



▲ Outlet Seal  
690-1827


▲ Inlet Seal  
690-1826

▲ Outlet Seal  
690-1827

## DEBRISTANK INLET/OUTLET SEALS



▲ Round Screen Weldment  
800-9535



▲ Debris Tank Prop  
800-0150



▲ Rear Door Cam Roller  
690-1770



▲ Ball Joint Rod End  
3/4-16 UNC Thread  
605-0147



▲ Cam Roller Spacer  
810-12001



▲ Rear Door Safety Latch Assembly  
711-0063



▲ Rear Door Seal  
(all models)  
690-1179



▲ Float Ball 6" diameter Plastic  
690-0023




▲ Float Ball 6" diameter Stainless Steel  
690-0745



▲ Arrowboard  
633-0069



▲ Replacement Control Box  
Superior Traffic Manager  
(for use with Arrowboard 633-0069)  
633-0303



▲ Circuit Board  
(for use with Control Box 633-0303)  
633-0262



▲ Replacement Control Box  
633-0149



▲ Replacement  
Circuit Board  
633-0263



▲ Arrowstick  
633-0375



▲ Replacement Control Box  
Superior Signal  
(for use with Arrowstick 633-0375)  
633-0407



▲ Amber Clearance Light  
633-0005



▲ Red Clearance Light  
633-0006



▲ Clearance Light Bar  
633-0256



▲ Beacon  
633-0464



▲ Strobe  
633-0008



▲ Handheld Spotlight

681-0054 for units built before September 1, 2004.  
 681-1005 for units after September 1, 2004  
 Replacement bulb: 690-0045



◀ Electric Cord Reel -  
 50 ft long cord  
 (for Handheld Spotlight)

711-0170 for units built before  
 September 1, 2004.  
 711-22329 For units after  
 September 1, 2004



▲ Handheld Spotlight  
 Replacement Outlet

631-0011 for units built before  
 September 1, 2004.



▲ Handheld Spotlight  
 Replacement Plug

631-0010 for units built before  
 September 1, 2004.



▲ Limit Switch

631-0043 (for Debris Tank Level  
 Indicator Arm and Articulating Hose  
 Reel Outrigger Leg)

Replacement lever and roller:  
 631-0244 (current style)  
 631-0044 (old style)



▲ Handheld Spotlight  
 Replacement Outlet

631-0477 for units built after  
 September 1, 2004.



▲ Handheld Spotlight  
 Replacement Plug

631-0491 for units built after  
 September 1, 2004.



▲ Limit Switch

631-0029 (for Vacuum  
 Breaker Hydraulic Cylinder)

Replacement lever and roller:  
 631-0244 (current style)  
 631-0044 (old style)





▲ Boom Joystick Switch  
631-0001



▲ Contact Block  
(for Boom Joystick 631-0001)  
631-0002 (each, 2 required)



▲ Emergency Engine Stop Switch  
(Truck and Auxiliary Engine)  
631-1061



▲ Auxiliary Engine Fuse Holder  
630-0022



▲ Auxiliary Engine Replacement Fuse-15 AMP  
630-0042



▲ Circuit Breaker

Part Number	Description
630-0081	5 AMP
630-0082	10 AMP
630-0083	15 AMP
630-0176	20 AMP
630-0198	25 AMP



▲ Auxiliary Engine Start/Stop Switch  
631-0014



▲ Auxiliary Engine Indicator Light  
633-0017



▲ Boom Pendant with  
3 Toggle Switches  
(for use with Fixed Boom)

711-3962 (up to May 31, 2002)

711-7639L030 (June 1, 2002 and later)



▲ Boom Pendant with  
4 Toggle Switches  
(for use with Telescopic Boom)

711-3960 (up to November 30, 2001)

After December 1, 2001, use 711-6988L030

711-6202 (3 yard machine with no vacuum breaker)



▲ Boom Pendant with  
5 Toggle Switches  
(for use with Telescopic Boom and  
Vacuum Breaker Control)

711-4907 (up to November 30, 2001)

711-6988L030 (December 1, 2001 and later)



▲ Hi-Dump Control Pendant

711-16327 (October 1, 2002 to November 3, 2003)


711-16329 (November 4, 2003 and later)




- ▲ **Omnex Wireless Controller**  
(for Omnex Wireless Transmitters)  
633-1088 for units with Emergency Stop Switch  
633-0888 for units without Emergency Stop Switch




- ▲ **Omnex Wireless Controller**  
*for use with Omnibus*  
(for Omnex Wireless Transmitters)  
633-1488 Omnex Model R170



- ◀ **Omnex Wireless Transmitter**  
633-0889 without Emergency Stop Switch  
692-2851 Replacement Decal



- ◀ **Omnex Wireless Transmitter**  
633-1089 with Emergency Stop Switch  
692-2851 Replacement Decal



- ◀ **Omnex Wireless Transmitter**  
*for use with Omnibus*  
633-1489 with Emergency Stop Switch  
692-2851 Replacement Decal



▲ Boom Pendant Replacement Push Button Switch

631-0012



▲ Boom Pendant Outlet

631-0192 (9 Pin)

631-0005 (8 Pin)



▲ Boom Pendant Replacement Toggle Switch ON/OFF Switch

631-0019



▲ Boom Pendant Plug

631-0193 (9 Socket)

631-0006 (8 Socket)



▲ Boom Pendant Replacement Toggle Switch ON/OFF/ON Switch - Momentary

631-0052



▲ Boom Pendant Replacement Wire (10 conductor) per foot

630-0301



▲ Kanaflex Hose-180AR-Vacuum Hose

Part Number	Description
680-0291	2.50"
680-0109	4.00"
680-0145	6.00"
680-0001	8.00"
680-0199	10.00"
680-0099	12.00"

Kanaflex Hose-390SD-Water Discharge

Part Number	Description
680-0245	2.00"
680-0238	3.00"
680-0298	4.00"



◀ 8.00" Cuffed Suction Hose

Part Number	Description
681-0051RV	66" long
681-0052RV	102" long
681-0053RV	127" long
681-00518	180" long



▲ Kanaflex Hose Clamps

Part Number	Description
680-0301	2.00"
680-0089	2.50"
680-0080	3.00"
680-0110	4.00"
680-0113	6.00"
680-0016	8.00"
680-0200	10.00"
680-0100	12.00"



◀ 8.00" Clamp for Cuffed Hose  
681-0062



▲ Hydrant Hose 2-1/2" x 25' long  
680-0029



▲ Hydrant Hose Adapter  
Female 2-1/2"  
663-0018  
Replacement Gasket: 663-0177



▲ Hydrant Hose Basket  
800-0192 (35 ft Capacity)  
800-0786 (50 ft Capacity)



▲ Hydrant Hose Adapter  
Male 2-1/2"  
663-0186



▲ Hydrant Hose Clamp  
680-0025



## ◀ Layflat Drain Hose

Part Number	Description
680-0218	2.00"
680-0076	3.00"
680-0188	4.00"
680-0002	6.00"
680-0279	8.00"



## ▲ Layflat Drain Hose Clamps

Part Number	Description
680-0251	2.00"
680-0025	2.50"
680-0124	3.00"
680-0026	4.00"
680-0064	6.00"



## ▲ Pipe Threaded Hose Nipples

Part Number	Description
663-0134	1.00"
663-0181	1.50"
663-0372	2.00"
663-0009	2.50"
663-0183	3.00"
663-0060	4.00"
663-0888	6.00"
663-0816	8.00"



◀ **Part A**  
**Adapter-Female Thread - Aluminum**

<u>Part Number</u>	<u>Description</u>
663-0839	1.50"
663-0692	2.00"
663-0306	2.50"
663-0083	3.00"
663-0366	4.00"
663-0264	6.00"
663-0652	8.00"



◀ **Part B**  
**Coupler-Male Thread - Aluminum**

<u>Part Number</u>	<u>Description</u>
663-0840	1.50"
663-0844	2.00"
663-0190	2.50"
663-0331	3.00"
663-0057	4.00"
663-0848	6.00"
663-0850	8.00"



◀ **Part C**  
**Coupler-Shank - Aluminum**

<u>Part Number</u>	<u>Description</u>
663-0223	1.50"
663-0403	2.00"
663-0225	2.50"
663-0079	3.00"
663-0270	4.00"
663-0265	6.00"
663-0835	8.00"





◀ **Part D**  
Coupler-Female Thread - Aluminum

Part Number	Description
663-0841	1.50"
663-0845	2.00"
663-0279	2.50"
663-0676	3.00"
663-0805	4.00"
663-0393	6.00"
663-0801	8.00"



◀ **Part E**  
Adapter Shank - Aluminum

Part Number	Description
663-0842	1.50"
663-0846	2.00"
663-0189	2.50"
663-0078	3.00"
663-0269	4.00"
663-0353	6.00"
663-0851	8.00"



◀ **Part F**  
Adapter-Male Thread - Aluminum

Part Number	Description
663-0337	1.50"
663-0401	2.00"
663-0224	2.50"
663-0694	3.00"
663-0333	4.00"
663-0314	6.00"
663-0852	8.00"



### ◀ Plug - Aluminum

Part Number	Description
663-0843	1.50"
663-0847	2.00"
663-0191	2.50"
663-0080	3.00"
663-0412	4.00"
663-0849	6.00"
663-0853	8.00"



### ◀ Dust Cap - Aluminum

Part Number	Description
663-0338	1.50"
663-0402	2.00"
663-0305	2.50"
663-0081	3.00"
663-0334	4.00"
663-0339	6.00"
663-0653	8.00"



### ◀ Brass Chain

(for use with Plug and Dust Cap)  
663-0082



▲ 1-1/4" NPT Hose Reel Rotary Union  
663-0002



▲ 1-1/4" Hose Reel Rotary Union Repair Kit  
663-0108



▲ 1-1/4" Rotary Union Packing  
663-0111



▲ 3/4" NPT Rotary Union  
663-0809



▲ 3 Way Manifold  
810-21149



▲ 3 Way Manifold  
810-29849



▲ Fixed Hose Reel Retaining Hitch Pin  
605-0008



▲ Articulating Hose Reel Retaining Hitch Pin  
605-0070



◀ Hose Reel Water Pressure Gauge  
0-3000 PSI  
665-0102 Pipe Thread  
624-0276 SAE Thread

621-1579 Adapter required to adapt pipe thread to SAE Hose connection



▲ Hose Reel Cleat  
690-0243

Mounting Screw-Flat Head Machine Screw 1/4-20UNC  
(2 required)  
601-0159



▲ Hose Reel Chain  
642-0026



▲ Connecting Link  
(for Chain 642-0026)  
642-0010



▲ Articulating Reel Chain  
642-0058



▲ Connecting Link  
(for Chain 642-0058)  
642-0005



▲ Throttle Cables

Part Number	Length
690-0047	120"
690-0032	180"
690-0390	220"
690-0046	256"
690-0104	276"
690-0196	292"
690-0269	320"
690-0392	360"
690-1216	380"
690-0850	420"

Replacement Head: 690-0614



▲ Hose Reel Support Jack  
Fixed Hose Reel

800-4632

Replacement Handle: 810-1991



▲ Rubber Roller for  
Hose Wind Guide

690-1758 - 4" dia x 3.75 long

690-0034 - 3" dia x 4" long



▲ Aluminum Roller for  
Hose Wind Guide

711-5873 - 4" dia x 4" long

711-1113 - 3" dia x 4" long



▲ Hose Reel Footage Counters-Measure in Feet

711-10751DR Curb Side Control Panel, Driver Side Counter Location, Non Omnibus Hose Reels

711-10758DR Curb Side Control Panel, Curb Side Counter Location, Omnibus Hose Reels

711-10759DR Driver Side Control Panel, Driver Side Counter Location, Omnibus Hose Reels



◀ Hose Reel Footage Counter Wheel

690-0195

▲ Hose Reel Footage Counter - Measure in Feet

690-0194 For use with 711-10751DR, 711-10758DR and 711-10759DR



▲ Hydraulic Cylinder  
(for Boom Lift)  
3.50" Bore x 7.00" Stroke  
620-0216 (replaces 620-0099 & 620-0209)



▲ Hydraulic Cylinder  
(for Articulating Hose Reel Outrigger Leg)  
3.00" Bore x 7.00" Stroke  
620-0210



▲ Hydraulic Cylinder  
(for Vacuum Breaker and Debris Tank Door Lock)  
2.00" Bore x 6.00" Stroke  
620-0002



▲ Hydraulic Cylinder  
(for Debris Tank Door Holder/Grabber)  
2.00" Bore x 6.00" Stroke  
620-0075



◀ Hydraulic Cylinder  
(for Vacuum Breaker - Spring Loaded)  
2.00" Bore x 4.38" Stroke  
620-0187



◀ Hydraulic Cylinder  
(for Scissor Lift 5-12 YD, 16 YD Debris Tanks)  
6.00" Bore x 18.00" Stroke  
620-0207



▲ Rexroth Hydrostatic Motor -  
Fan Vacuum Systems  
622-0024



▲ Rexroth Hydrostatic Motor -  
Roots 8" PD Blowers  
622-0139



▲ VOAC Hydrostatic Motor -  
Fan Vacuum Systems  
622-0219



▲ Hydrostatic Cooler Motor  
624-0050





▲ Hydraulic Return Spin-on Filter  
624-0009



▲ Hydrostatic Charge Pump Spin-on Filter - Rexroth  
624-0083



▲ Hydrostatic Charge Pump Filter Element  
624-0158



▲ Hydrostatic Filter Housing includes Filter with Pop-Up Condition Indicator  
624-0020



▲ Hydrostatic Charge Pump Spin-on Filter - Eaton  
622-0581



▲ Hydrostatic Filter Element  
(for Filter Housing 624-0020)  
624-0029



◀ Replacement Pop-up Condition Indicator  
(for Filter Housing 624-0020)  
624-0035



▲ Hydraulic Reservoir  
Level Gauge  
624-0224



◀ Hydraulic Reservoir  
Return Filter Housing  
624-0260



◀ Hydraulic Reservoir  
Return Filter Element  
(for Filter Housing 624-0260)  
624-0261



▲ Hydraulic Filter Element  
(for Filter Housing 624-0271)  
624-0272



◀ Hydraulic Reservoir  
Return Filter Gauge  
(for Filter Housing 624-0260)  
624-0298



▲ Pressure Gauge  
0-3000 PSI  
665-0005 Pipe Thread  
624-0255 SAE Thread



▲ Pressure Gauge  
0-10000 PSI  
624-0021 Pipe Thread  
624-0256 SAE Thread



▲ Pressure Gauge  
0-3000 PSI  
665-0102 Pipe Thread  
624-0276 SAE Thread



▲ Pressure Gauge  
0-5000 PSI  
665-0091 Pipe Thread  
624-0277 SAE Thread

621-1579 Adapter required to adapt pipe thread to SAE Hose connection

Replacement Handle: 623-0024  
Replacement Handle Bracket: 623-0033  
Replacement Knob: 623-0035  
Replacement O-Ring: 623-0031  
Replacement Seal: 623-0032



▲ Hose Reel Control Valve  
623-0003

Replacement Handle: 623-0166  
Replacement Pin Kit: 623-0168  
Seal Kit: 623-0175



▲ Articulating Hose Reel/  
Outrigger Control Valve  
623-0112



▲ Articulating Hose  
Reel/Outrigger  
Selector Valve  
623-0055  
Replacement Knob: 623-0120



▲ Cartridge Valve  
623-0100



▲ Solenoid Operated Hydraulic  
Control Valve  
623-0006



### ◀ Mud Flaps

Part Number	Description
690-0029	Mud Flap with Vac-Con Logo (pair)
690-0149	Mud Flap with no logo (each)
690-0379	Anti-Sail Mud Flap Bracket (pair)



### ▲ Logo Decals - Red and Gray on Clear Vinyl

Part Number	Description
692-3001	10.40" x 48.00"
692-3003	3.00" x 13.80"



### ▲ Logo Decals - White on Clear Vinyl

Part Number	Description
692-3002	10.40" x 48.00"
692-3004	3.00" x 13.80"



- ▲ Serial Plate Assembly  
Includes Mounting Hardware  
(Specify Serial Number)  
711-0466



- ▲ Made In USA Decal  
692-0333



◀ Traffic Cone  
28" Tall  
690-1480



▲ Triangle Kit  
(3) Triangles and Box  
690-0494



◀ Fire Extinguisher  
5 lb Fire Extinguisher  
711-1326



▲ Flare Kit  
Includes (3) flares  
690-0560



◀ First Aid Kit  
690-0500



◀ Red Reflector  
690-0018



◀ Yellow Reflector  
690-0019



◀ Pop Rivet  
(2) required for reflectors  
605-0014



## ◀ Sewer Cleaning Hose-Piranha

Part Number	Description
664-0099P	3/4" Bulk, 3000 PSI
664-0167P	3/4" x 200 ft, 3000 PSI
664-0077P	3/4" x 400 ft, 3000 PSI
664-0078P	3/4" x 500 ft, 3000 PSI
664-0079P	3/4" x 600 ft, 3000 PSI
664-0117P	3/4" x 800 ft, 3000 PSI
664-0036	1" Bulk, 2500 PSI
664-0121P	1" x 200 ft, 2500 PSI
664-0005P	1" x 400 ft, 2500 PSI
664-0002P	1" x 500 ft, 2500 PSI
664-0004P	1" x 600 ft, 2500 PSI
664-0158P	1" x 800 ft, 2500 PSI
664-0200P	1" x 400 ft, 3000 PSI
664-0216P	1" x 500 ft, 3000 PSI
664-0199P	1" x 600 ft, 3000 PSI

## Sewer Cleaning Hose - Cobra


Part Number	Description
664-0245C	3/4" Bulk, 3000 PSI
664-0240C	3/4" x 400 ft, 3000 PSI
664-0241C	3/4" x 500 ft, 3000 PSI
664-0242C	3/4" x 600 ft, 3000 PSI
664-0243C	3/4" x 800 ft, 3000 PSI
664-0239C	1" Bulk, 2500 PSI
664-0235C	1" x 400 ft, 2500 PSI
664-0236C	1" x 500 ft, 2500 PSI
664-0237C	1" x 600 ft, 2500 PSI
664-0238C	1" x 800 ft, 2500 PSI
664-0250C	1" Bulk, 3000 PSI
664-0246C	1" x 400 ft, 3000 PSI
664-0247C	1" x 500 ft, 3000 PSI
664-0248C	1" x 600 ft, 3000 PSI

## Sewer Cleaning Hose - Parker-Dayco-Eastman

Part Number	Description
664-0180I	3/4" x 400 ft, 3000 PSI
664-0181I	3/4" x 500 ft, 3000 PSI
664-0155I	3/4" x 600 ft, 3000 PSI
664-0178I	3/4" x 800 ft, 3000 PSI
664-0187I	1" Bulk, 2500 PSI
664-0118I	1" x 400 ft, 2500 PSI
664-0002I	1" x 500 ft, 2500 PSI
664-0004I	1" x 600 ft, 2500 PSI
664-0126I	1" x 800 ft, 2500 PSI
664-0159I	1" Bulk, 3000 PSI
664-0134I	1" x 400 ft, 3000 PSI
664-0135I	1" x 500 ft, 3000 PSI
664-0136I	1" x 600 ft, 3000 PSI
664-0133I	1" x 700 ft, 3000 PSI
664-0189I	1" x 800 ft, 3000 PSI

## Sewer Cleaning Hose - Aeroquip

Part Number	Description
664-0074A	3/4" x 400 ft, 3000 PSI
664-0085A	3/4" x 500 ft, 3000 PSI
664-0086A	3/4" x 600 ft, 3000 PSI
664-0097A	3/4" x 1000 ft, 3000 PSI
664-0005A	1" x 400 ft, 2500 PSI
664-0002A	1" x 500 ft, 2500 PSI
664-0004A	1" x 600 ft, 2500 PSI
664-0094A	1" x 400 ft, 3000 PSI
664-0095A	1" x 500 ft, 3000 PSI
664-0096A	1" x 600 ft, 3000 PSI
664-0081A	1-1/4" Bulk, 2500 PSI
664-0098A	1-1/4" x 500 ft, 2500 PSI
664-0128A	1-1/4" x 600 ft, 2500 PSI



▲ Sewer Cleaning Leader Hose

Part Number	Description
512G036CC00	-12 (3/4") x 36" long 3000 PSI maximum
512G060CC00	-12 (3/4") x 60" long 3000 PSI maximum
512G072CC00	-12 (3/4") x 72" long 3000 PSI maximum
512G120CC00	-12 (3/4") x 120" long 3000 PSI maximum
516G036CC00	-16 (1") x 36" long 3000 PSI maximum
516G060CC00	-16 (1") x 60" long 3000 PSI maximum
516G072CC00	-16 (1") x 72" long 3000 PSI maximum
516G120CC00	-16 (1") x 120" long 3000 PSI maximum
520G036CC00	-20 (1-1/4") x 36" long 2000 PSI maximum
520G060CC00	-20 (1-1/4") x 60" long 2000 PSI maximum
520G072CC00	-20 (1-1/4") x 72" long 2000 PSI maximum
520G120CC00	-20 (1-1/4") x 120" long 2000 PSI maximum



▲ Flexible Hose Guide

665-0004



◀ Nozzle Pipe Assembly

Part Number	Description
711-19651	for 3/4" Nozzles
711-19653	for 1" Nozzles
711-19654	for 1-1/4" Nozzles



▲ Lateral Line Cleaning Kit

Part Number	Description
711-6341H050	1/2" x 50 ft long hose
711-6341H100	1/2" x 100 ft long hose
711-6341H150	1/2" x 150 ft long hose
711-6341H200	1/2" x 200 ft long hose

Replacement Nozzle: 681-0323  
Rear Frame Mount Kit: 711-30251



◀ Manhole Roller Assembly

711-0050

To place your order call your dealer or Vac-Con 1-904-284-4200





### ◀ Hydraulic Swage Mending Kit Piranha Sewer Hose

Part Number	Description
681-0972	3/4" Hose
681-0973	1" Hose

### Hydraulic Swage Mending Kit Parker-Dayco-Eastman Sewer Hose

Part Number	Description
681-0606	3/4" Hose
681-0603	1" Hose

### Hydraulic Swage Mending Kit Cobra Sewer Hose

Part Number	Description
681-1159	Does not include menders, dies or pushers

### ◀ Die Pair Piranha Sewer Hose (2 required)



Part Number	Description
664-0093	3/4" Hose
681-0081	1" Hose

### Die Pair Parker-Dayco-Eastman Sewer Hose (2 required)

Part Number	Description
681-0616	3/4" Hose
664-0137	1" Hose

### Die Pair Cobra Sewer Hose (2 required)

Part Number	Description
681-1160	3/4" Hose
664-1161	1" Hose



### ◀ Pusher Piranha Sewer Hose (1 required)

Part Number	Description
664-0057	3/4" Hose
664-0073	1" Hose

### Pusher Parker-Dayco-Eastman Sewer Hose (1 required)

Part Number	Description
664-0108	3/4" Hose
664-0138	1" Hose

### Pusher Cobra Sewer Hose (1 required)

Part Number	Description
664-1162	3/4" Hose

### ◀ Hose End Piranha Sewer Hose



Part Number	Description
664-0084	3/4" Hose
621-0019	1" Hose

### Hose End Parker-Dayco-Eastman Sewer Hose

Part Number	Description
681-0608	3/4" Hose
681-0604	1" Hose

### Hose End Cobra Sewer Hose

Part Number	Description
681-1155	3/4" Hose
681-1156	1" Hose

### ◀ Hose Mender Piranha Sewer Hose



Part Number	Description
664-0092	3/4" Hose
681-0007	1" Hose

### Hose Mender Parker-Dayco-Eastman Sewer Hose

Part Number	Description
681-0607	3/4" Hose
681-0605	1" Hose

### Hose Mender Cobra Sewer Hose

Part Number	Description
681-1157	3/4" Hose
681-1158	1" Hose



▲ Hinge  
690-0489



▲ Hinge  
690-0492



▲ Lift and Turn Latch  
690-0095



▲ Paddle Latch  
690-0105



▲ Concealed Hinge  
690-1005



▲ T Handle Latch  
690-0439




▲ 9 Hole "L" Hinge  
(for Deck Mounted Tool Box)  
681-0898



▲ 7 Hole "L" Hinge  
(for Storage Box - 2 per door)  
681-0905



▲ T Handle Latch  
681-0897



▲ Dri-Deck 12" x 12"  
Square-Black  
690-0950



▲ Grease Gun  
690-0093



▲ Grease Tube - Synthetic  
(for Fan Vacuum Compressor Bearings)  
690-0041



▲ Grease Tube  
(for General Purpose Use)  
690-1419



◀ Manhole Lifting Hook  
681-0084



◀ Hydrant Wrench  
690-0096



◀ Aluminum Suction Tube with Vac-Con Flanges at Both Ends

(for use with Vac-Con Quick Clamps)

**6.00" Diameter**

Part Number	Description
800-3203	3'-0" long
800-9304	4'-0" long
800-3204	5'-0" long
800-3205	6'-0" long
800-4930	8'-0" long
800-6430	10'-0" long
800-8010	16'-0" long

**8.00" Diameter**

Part Number	Description
800-0262	2'-0" long
800-0063	3'-0" long
800-0347	4'-0" long
800-0064	5'-0" long
800-0089	6'-0" long
800-0352	7'-0" long
800-0261	8'-0" long
800-0133	10'-0" long
800-3290	12'-0" long
800-7391	15'-0" long
800-8009	16'-0" long

**12.00" Diameter**

Part Number	Description
800-5272	2'-0" long
800-5271	4'-0" long

▶ Rotary Pipe Rack (pipe not included)

711-7444 Holds 4 pipes

711-5445 Holds 5 pipes



◀ Aluminum Catch Basin Nozzles with Vac-Con Flanged End (for use with Vac-Con Quick Clamps)

**6.00" Diameter**


Part Number	Description
800-5096	4'-0" long (with holes)
800-3202	6'-6" long (with holes)
800-4553	8'-0" long (8" Flange)

**8.00" Diameter**

Part Number	Description
800-3932	1'-0" long (no holes)
800-0088	2'-0" long (no holes)
800-0348	2'-0" long (with holes)
800-0819	4'-0" long (with holes)
800-7388	5'-0" long (with holes)
800-0065	6'-6" long (with holes)
800-0572	7'-6" long (no holes)
800-3579	8'-0" long (with holes)
800-0448	9'-0" long (with holes)
800-3529	10'-0" long (with holes)
800-7383	12'-6" long (with holes)

**12.00" Diameter**

Part Number	Description
800-5274	6'-0" long





▲ Non-Conductive Catch Basin Nozzles with Vac-Con Flange

6.00" Diameter

Part Number	Description
711-7441	6'-0" LG

8.00" Diameter

Part Number	Description
711-0364	6'-0" LG



◀ Clear Demo Tube Assembly with Vac-Con Flanges

Part Number	Description
711-5318	6.00"
711-1255	8.00"



▲ Air Regulator with Vac-Con Flanges

Part Number	Description
711-4478	6.00"
711-1248	8.00"



▲ Circular Operator Handle

Part Number	Description
711-6279	for 6.00" Tube
711-0172	for 8.00" Tube
711-5302	for 12.00" Tube



▲ Repair Suction Tube Flange for Vac-Con Suction Tube and Suction Nozzles

Part Number	Description
680-0204	6.00" Aluminum
680-0314	6.00" Steel
680-0009	8.00" Aluminum
690-0024	8.00" Steel (with holes)
690-1017	8.00" Steel (without holes)



▲ Repair Nozzle Crown for Vac-Con Suction Nozzles

Part Number	Description
810-3907	6.00"
810-0222	8.00"
810-20014	12.00"



▲ Gasket for Vac-Con Suction Tubes and Suction Nozzles

Part Number	Description
690-0380	6.00"
690-0025	8.00"
690-1287	9.00"
690-1284	10.00"



▲ Quick Clamp for Vac-Con Suction Tubes and Suction Nozzles

Part Number	Description
800-7633	4.00"
800-0132	5.00"
680-0073	6.00"
680-0015	8.00"
680-0163	9.00"
680-0340	10.00"
800-0445	12.00"



◀ Bungee Cord for Suction Tube Racks  
690-0030



▲ Flat Flange to Double Hose Adapter

Part Number	Description
800-0476	8.00" Flange to double 4.00" Hose Steel
800-0697	8.00" Flange to double 6.00" Hose Steel
800-3315	8.00" Flange to double 4.00" Pipe Thread Steel
800-9404	8.00" Flange to double 4.00" Flange Steel



▲ Flat Flanged to Hose End Adapter

Part Number	Description
800-5438	6.00" Flange to 6.00" Hose Steel
800-7374	8.00" Flange to 8.00" Hose Aluminum
800-0097	8.00" Flange to 8.00" Hose Steel-with mounting holes
800-5046	8.00" Flange to 8.00" Hose Steel-no mounting holes
800-6348	10.00" Flange to 10.00" Hose Steel-with mounting holes
800-0406	12.00" Flange to 12.00" Hose Steel-with mounting holes



▲ Flat Flange to Hose End Reducer Adapter

Part Number	Description
800-4557	6.00" Flange to 3.00" Hose Steel
800-8005	6.00" Flange to 4.00" Hose Steel
800-7371	8.00" Flange to 3.00" Hose Steel
800-4319	8.00" Flange to 4.00" Hose Steel
800-5994	8.00" Flange to 4.00" Pipe Thread Steel
800-0351	8.00" Flange to 6.00" Hose Steel



▲ Flat Flange to Flange Adapter

Part Number	Description
800-8021	6.00" Flange to 4.00" Flange Steel-with mounting holes
800-7373	8.00" Flange to 4.00" Flange Steel-with 8" mounting holes only
800-0647	8.00" Flange to 6.00" Flange Steel-with mounting holes
800-10854	12.00" Flange to 8.00" Flange Steel-with mounting holes
800-5273	12.00" Flange to 8.00" Flange Aluminum-no mounting holes



▲ Flat Flange to Male Band Lock Adapter

Part Number	Description
800-5071	6.00" Flange to 6.00" Band Lock Steel-with mounting holes
800-2217	8.00" Flange to 8.00" Band Lock Steel-with mounting holes



▲ Flat Flange to Female Band Lock Adapter

Part Number	Description
800-6164	8.00" Flange to 6.00" Band Lock Steel-with mounting holes
800-7399	8.00" Flange to 6.00" Band Lock Aluminum-with mounting holes
800-3244	8.00" Flange to 8.00" Band Lock Steel-with mounting holes





▲ Band Lock Male Press-In Coupler for Hose

Part Number	Description
690-0678	4.00"-Steel
690-0733	6.00"-Steel
690-0679	8.00"-Steel
690-0861	12.00"-Steel



▲ Band Lock Female Press-In Coupler for Hose

Part Number	Description
690-0676	4.00"-Steel
690-0732	6.00"-Steel
690-0677	8.00"-Steel
690-0862	12.00"-Steel



▲ Band Lock Male Plug

Part Number	Description
690-0738	6.00"-Steel
690-0684	8.00"-Steel
690-0863	12.00"-Steel



▲ Band Lock Gasket for Female Couplers

Part Number	Description
690-0699	6.00"
690-0681	8.00"
690-0864	12.00"



▲ Band Lock Reducer Male to Female

Part Number	Description
690-0735	8.00" Male to 6.00" Female-Steel



▲ Band Lock Clamp

Part Number	Description
690-0700	6.00"
690-0683	8.00"
690-0865	12.00"



◀ Vacuum Compressor  
Clean-Out Box Door Gasket  
690-0245



▶ Vacuum Compressor  
Clean-Out Box Door Latches  
(Pair with Mounting Hardware)  
711-6342



◀ Final Filter Bag  
613-0058  
  
HEPA Style Bag  
613-0060



◀ Pleated Cartridge Filter

Part Number	Description
613-0078	4.875" dia. x 41.25" long
613-0094	5.625" dia. x 41.25" long



◀ Star Filter Bag  
613-0163



◀ Filter Cage  
(for use with Filter Bag 613-0163)  
613-0164



◀ Complete Hydrostatic Coupling

Part Number	Description
644-0035	Hydrostatic Fan
644-0085	Hydrostatic PD Blower



▲ Keyed Coupler Half  
644-0020 (Fan)  
644-0151 (PD Blower)

▲ Metal Ring  
644-0041

▲ Rubber Insert  
644-0040

▲ Splined Coupler Half  
644-0022 (Fan)  
644-0181 (PD Blower)



▲ Baird 3000 PSI Pressure Relief Valve  
662-0202



▲ Baird 650 PSI Pressure Relief Valve  
662-0004



▲ Spray Systems Handgun 650 PSI Pressure Relief Valve  
662-0053



▲ Water Pump Drain Valve 1/8" NPT  
623-0228



▲ Needle Valve 1/2" NPT  
623-0016



▲ Cat Pumps Handgun Unloader Valve  
662-0263



▲ Hycon 1"  
3 Way Ball Valve  
662-0003 - 2500 PSI



▲ Hycon 1"  
2 Way Ball Valve  
662-0205 - 3000 PSI



▲ Hycon 1-1/4"  
2 Way Ball Valve  
662-0207 - 5000 PSI



▲ Dynaquip 1"  
2 Way Ball Valve  
662-0017 - 3000 PSI



▲ Nells Jamesbury 1"  
2 Way Ball Valve  
662-0106 - 3000 PSI



▲ Stauff 1"  
2 Way Ball Valve  
662-0282



▲ Apollo 3/4"  
2 Way Ball Valve  
662-0006 - 3000 PSI



▲ Dynaquip 1/2"  
2 Way Ball Valve  
662-0044 - 2000 PSI



▲ Dynaquip 1/4"  
2 Way Ball Valve  
662-0094 - 3000 PSI



◀ **Butterfly Valve**

Part Number	Description
662-0013	3.00"
662-0193	4.00"
662-0127	5.00"
662-0218	6.00"
662-0189	8.00"
662-0213	12.00"

**Knife Valve** ▶

Part Number	Description
662-0125	6.00"
662-0121	8.00"



**Replacement O-Rings**  
(2) Required

Part Number	Description
662-0126	6.00"
662-0122	8.00"



◀ **Gate Valve**

Part Number	Description
662-0029	1.00" NPT
662-0059	1.50" NPT
662-0030	2.00" NPT
662-0008	2.50" NPT
662-0060	3.00" NPT
662-0009	4.00" NPT
662-0026	8.00" NPT

## ◀ Low Pressure Handgun Hose Reel

Part Number	Description
711-20028H035	35 ft long hose
711-20028H050	50 ft long hose
711-20028H075	75 ft long hose
711-20028H100	100 ft long hose



## ▲ 1/2" Low Pressure Handgun Hose Assembly

Part Number	Description
711-43301H025	25 ft long
711-43301H035	35 ft long
711-43301H050	50 ft long
711-43301H100	100 ft long
711-43301H200	200 ft long



▲ Low Pressure Handgun  
680-0010

Repair Kit: 680-0030

Replacement Tip: 680-0031

## ▲ 1/2" High Pressure Handgun Hose Assembly

Part Number	Description
711-43301A025	25 ft long
711-43301A035	35 ft long
711-43301A050	50 ft long
711-43301A100	100 ft long
711-43301A200	200 ft long

◀ Handgun Female Quick Disconnect  
1/2" NPT Thread  
663-0003



▲ Handgun Hose Reel Ball Stop  
681-0118

◀ High Pressure Handgun Female Quick Disconnect  
1/2" NPT Thread  
663-0706



◀ Handgun Male Quick Disconnect  
1/2" NPT Thread  
663-0004

◀ High Pressure Handgun Male Quick Disconnect  
1/2" NPT Thread  
663-0705





▲ Lower Water Tank  
665-0043



▲ Upper Rear Water Tank  
665-0244



▲ Hot Shot Water Tank Lid  
and Mounting Flange  
665-0075  
Lid Center  
665-0088



▲ Lower Water Tank Lid  
665-0017

Mounting Flange  
665-0018



▲ Upper Rear Water  
Tank Lid  
665-0026

Mounting Flange  
665-0027



▲ Water System  
Vent Filter  
610-0098



◀ Water Tank Level  
Gauge Assembly  
711-0662



▲ Water System  
1" Vent Tubing  
664-0060





▲ 1" NPT Rotary Union  
663-0001



▲ 1-1/4" NPT Rotary Union  
663-0002



▲ Rotary Union Repair Kit

Part Number	Description
663-0104	1" Seal Kit
663-0108	1-1/4" Seal Kit



▲ Rotary Union Packing  
(for 663-0001 and 663-0002)  
663-0111



▲ 3/4" NPT Rotary Union  
663-0809



▲ 3 Way Manifold  
810-21149



▲ 3 Way Manifold  
810-29849



▲ Winter Water Recirculation Option with Ball Valve

Part Number	Description
711-19601	3/4" Water System - Contact Vac-Con for complete part number
711-19602	1.00" Water System - Contact Vac-Con for complete part number
711-19603	1.25" Water System - Contact Vac-Con for complete part number



▲ Brass Flushing Nozzle

Part Number	Description
681-0175	3/4" NPT Thread
681-0045	1.00" NPT Thread



▲ 8" Water Ring  
711-0214



▲ Nozzle Storage Rack

Part Number	Description
800-0866	3/4" Nozzle
800-0152	1.00" Nozzle
800-3039	1-1/4" Nozzle



▲ Water System "Y" Type Strainer

Part Number	Description
665-0010	1.00" NPT
665-0042	1.50" NPT
665-0077	2.00" NPT
665-0011	2.50" NPT
665-0049	3.00" NPT

# Water System



▲ Fuel Filter - Deutz  
650-1248



▲ Air Filter - Outer - Deutz  
650-1250



▲ Air Filter - Inner - Deutz  
650-1250



▲ Fuel / Water Separator - Deutz  
650-1441 Separator Assy (shown)  
650-1253 Replacement Element



▲ Air Filter - Outer - Deutz  
650-1254



▲ Fuel Pre Filter - Deutz  
650-1538



▲ Fuel Filter - Deutz  
650-1539



▲ Fuel Filter - Deutz  
650-1589

To place your order call your dealer or Vac-Con 1-904-284-4200

<b>A</b>		Layflat Hose.....	23
Air Filters - Auxiliary Engine .....	59	Quick Type for Suction Tubes.....	47
Air Regulator.....	46	Clearance Lights .....	15
Anti-Sail Mud Flap Bracket .....	36	Clear Demo Tube .....	46
Arrowboards and Control Boxes.....	13	Connecting Links	
Arrowsticks and Control Boxes .....	14	Boom Chain.....	8
Auxiliary Engine Air Filters.....	59	Hose Reel Chain.....	28
Auxiliary Engine Fuel and Water Separators .....	59	Control Boxes-Arrowboard .....	13
Auxiliary Engine Fuel Filters .....	59	Control Boxes-Arrowstick .....	14
Auxiliary Engine Fuse and Holder .....	17	Couplers-Cam-Lock .....	24
Auxiliary Engine Indicator Light .....	17	Coupling-Hydrostatic Drive .....	51
Auxiliary Engine Start/Stop Switch .....	17	Cuffed Hose.....	21
		Cuffed Hose Clamps .....	21
		Cylinders-Hydraulic .....	31
<b>B</b>		<b>D</b>	
Ball Stops for Handgun Hose Reels.....	55	Debris Tank Ball Joint Rod End .....	12
Ball Valves.....	53	Debris Tank Door Cam Roller .....	12
Band Lock Components.....	48	Debris Tank Door Cam Roller Spacer .....	12
Beacon Lights.....	15	Debris Tank Door Safety Latch .....	12
Bearings		Debris Tank Door Seal.....	12
Flange .....	6	Debris Tank Float Balls .....	12
Pillow Block.....	6	Debris Tank Inlet/Outlet Seals .....	10-11
Bearing Support Post .....	6	Debris Tank Prop.....	11
Belts-Drive .....	7	Debris Tank Vacuum Breaker Seals .....	10-11
Boom Chain Connecting Links .....	8	Decals .....	36
Boom Elbows .....	9	Demo Suction Tube-Clear.....	46
Boom Hose Reducers .....	9	Dies-Sewer Cleaning Hose Mender.....	41
Boom Gear Box .....	8	Dri-Deck for Tool Boxes .....	43
Boom Hyd. Cylinder Seal Kits.....	8	Drive Belts .....	7
Boom Joystick Contact Blocks.....	17		
Boom Joystick Switches.....	17	<b>E</b>	
Boom Pendants.....	18	Electric Cord Reels .....	16
Boom Pendant Outlet.....	20	Emergency Engine Stop Switch .....	17
Boom Pendant Plug.....	20		
Boom Pendant Switches .....	20	<b>F</b>	
Boom Pendant Wire.....	20	Fuel Filters - Auxiliary Engine.....	59
Boom Rotation Chain .....	8	Filters	
Boom Tie Down Latch.....	8	Auxiliary Engine.....	59
Brass Flushing Nozzle .....	58	Final Filter Bags .....	50
Bungee Cords for Suction Tube Racks .....	47	HEPA Style .....	50
		Hydraulic Spin-On .....	33
		Hydrostatic .....	33
		Pleated Cartridge .....	50
		Water Tank Vent.....	56
		Fire Extinguisher .....	37
		First Aid Kit .....	37
		Flange Bearings.....	6
		Flanges-Suction Tube .....	47
		Flares .....	37
		Flexible Hose Guide.....	40
		Footage Counters-Hose Reel .....	30
		Fuse Holder-Aux Engine.....	17
		Fuse-Aux Engine .....	17
<b>C</b>			
Cables-Throttle.....	29		
Cam-Lock Adapters .....	24-26		
Cam Rollers-Debris Tank Door.....	12		
Catch Basin Nozzles-Aluminum .....	45		
Catch Basin Nozzles-Non Conductive .....	46		
Chain			
Boom .....	8		
Hose Reel .....	28		
Circuit Breakers .....	17		
Circuit Boards-Arrowboard.....	13		
Circuit Boards-Arrowstick .....	14		
Circular Operator Handle.....	46		
Clamps			
Hydrant Hose .....	22		
Kanaflex Hose.....	21		

## G

Gaskets (see also Seals)	
Band Lock	49
Suction Tubes and Nozzles	45
Vacuum Compressor Clean-out Door	50
Gauges	
Hose Reel Water Pressure	29
Hydraulic Pressure	35
Water Tank Level	56
Grease Guns and Grease	40

## H

Handguns	55
Handgun Hose	55
Handgun Hose Reel	55
Handgun Hose Reel Ball Stop	55
Handgun Relief Valves	52
Handgun Quick Disconnect Fittings	55
Handheld Spotlights	16
Hi-Dump Pendant	18
Hinges-Storage Box	42
Hose Nipples	23
Hose	
Cuffed Suction	21
Handgun	55
Hydrant Hose	22
Kanaflex Suction	21
Sewer Cleaning	39
Sewer Cleaning Leader	40
Hose Basket-Hydrant Hose	22
Hose Clamps	
Cuffed Hose	21
Hydrant Hose	22
Kanaflex Hose	21
Hose Footage Counter-Sewer Hose	30
Hose Footage Counters and Parts	30
Hose Guide-Flexible	40
Hose Reel Ball Stop	55
Hose Reel Cleats	27
Hose Reel Hitch Pins	27
Hose Reel Jacks	29
Hose Reel Manifold-3 Way	27
Hose Reel Rollers	29
Hose Reel Rotary Unions and Packing	27
Hose Reel Water Pressure Gauge	28
Hose Reels-Handgun	55
Hydrant Hose	22
Hydrant Hose Adapters	22
Hydrant Hose Basket	22
Hydrant Hose Clamps	22
Hydrant Wrench	44
Hydraulic Cylinders	31
Hydraulic Reservoir Level Gauge	34
Hydraulic Reservoir Return Filter	34
Hydraulic Reservoir Return Filter Gauge	34
Hydraulic Valves - see Valves	

Hydrostatic Drive Couplings	51
Hydrostatic Filters and Indicators	33
Hydrostatic Motors	32

## J

Jacks-Hose Reel	29
-----------------	----

## K

Kanaflex Hose	21
Kanaflex Hose Clamps	21

## L

Labels - see Decals	
Latches	
Debris Tank Door Safety	12
Tool Box	42
Vacuum Compressor Clean-out Door	50
Lateral Line Cleaning Kit	40
Layflat Drain Hose	23
Layflat Drain Hose Clamps	23
Leader Hose-Sewer Cleaning	40
Lights	
Arrowboards	13
Arrowstick	14
Auxiliary Engine Indicator	17
Beacon	15
Clearance	15
Handheld Spotlight	16
Strobe	15
Limit Switches	16

## M

Manhole Lifting Hook	44
Manhole Roller Guide	40
Motors-Hydrostatic	32
Mud Flaps	36

## N

Nozzles	
Brass Flushing	58
Nozzle Pipe Weldments	40
Nozzle Storage Rack	58

## O

Omnex Controllers and Transmitters	19
Operator Handle-Suction Pipe	46

## P

Pendants .....	18
Pillow Block Bearings .....	6
Pipe Rack Assembly - Rotary .....	45
Pipe Threaded Hose Nipples .....	23
Pop Rivets for Reflectors .....	38
Pressure Gauge - see Gauges	
Prop-Debris Tank.....	11
Pusher-Sewer Cleaning Hose Mender .....	41

## Q

Quick Disconnect-Handgun Hose .....	55
-------------------------------------	----

## R

Rear Door Cam Roller .....	12
Rear Door Cam Roller Spacer.....	12
Recirculation Option-Winter Water .....	58
Reflectors.....	38
Relief Valves.....	52
Rollers-Hose Reel .....	29
Rotary Pipe Rack Assembly.....	45
Rotary Unions	
Hose Reel .....	27, 57
Sewer Cleaning Nozzle.....	57
Rotary Union Packing and Repair Kits .....	27, 57

## S

Safety Flares .....	37
Safety/Traffic Cone .....	37
Safety Triangles .....	37
Seals (see also Gaskets)	
Debris Tank Inlet/Outlet .....	10,11
Rear Door.....	12
Vacuum Breaker .....	10
Seal Kits-Telescopic Boom.....	8
Selector Valve-Hydraulic .....	35
Serial Plates.....	36
Sewer Cleaning Hose .....	38
Sewer Cleaning Hose Ends .....	41
Sewer Cleaning Hose Swage Menders.....	41
Sewer Cleaning Leader Hose.....	40
Spotlights.....	16
Spotlight Cord Reels .....	16
Spotlight Outlets.....	16
Spotlight Plugs .....	16
Star Final Filter Bag and Cage .....	50
Strainer-Y Type Water .....	58
Strobe Lights .....	15
Suction Adapters .....	48
Suction Catch Basin Nozzles.....	45
Suction Tubes-Aluminum .....	45
Suction Tube Bungee Cords.....	47

Suction Tube Clamps.....	47
Suction Tube Gaskets .....	47
Suction Tube Operator Handle .....	46
Suction Tube Repair Crowns .....	47
Suction Tube Repair Flanges .....	47
Swage Menders-Sewer Cleaning Hose .....	41
Switches	
Auxiliary Engine Start/Stop.....	17
Boom Joystick .....	17
Boom Pendant .....	18
Emergency Engine Stop.....	17
Limit .....	16

## T

Tool Box Hinges and Latches.....	42,43
Throttle Cables.....	29
Traffic Cones.....	37
Triangles.....	33

## V

Vacuum Breaker Hydraulic Cylinder .....	31
Vacuum Breaker Seals.....	10
Vacuum Final Filter Bags .....	50
Vacuum Screens .....	10,11
Vacuum Tube - see Suction Tube	
Valves	
Ball .....	53
Butterfly .....	54
Gate .....	54
Handgun Pressure Relief .....	52
Hydraulic Cartridge .....	35
Knife.....	54
Needle.....	52
Relief Valves-Water .....	52
Unloader-Water .....	52
Water Pump Drain .....	52

## W

Water Pump Drain Valves .....	52
Water Ring.....	58
Water System Vent Filter .....	56
Water System Vent Tubing .....	56
Water Tanks.....	56
Water Tank Level Gauge.....	56
Water Tank Lids .....	56
Winter Water Recirculation Option .....	58
Wireless Transmitters and Controllers .....	19

## Y

Y Type Water System Strainer .....	58
------------------------------------	----





969 Hall Park Drive . Green Cove Springs, FL 32043

Ph: 904.284.4200 . Fx: 904.529.7874 . [www.vac-con.com](http://www.vac-con.com)